

PINEOMATIC




SPARE PARTS CATALOG 2026

12/08/2026

WWW.ZUMEX.COM


SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0000188:00	CLOSING RING BEARING	Closing ring bearing Valid for all Pineomatic V5.1 and V6 machines.	
BME0000189:00	FILLING RING	Filling ring Valid for all Pineomatic V5.1 and V6 machines	
BME0000203:00	SHAFT SPRING SHUTTER	Shaft spring shutter Valid for all Pineomatic V5.1 and V6 machines	
BME0000206:00	SPRING SHUTTER	Spring shutter Valid for all Pineomatic V5.1 and V6 machines	
BME0000239:00	FILTRO BANDEJA DE GOTEO	Driptray filter Valid for all Pineomatic V4 machines	
BME0000624:00	ROLLED THREAD BALL SCREW	Rolled Thread Ball Screw Valid for all Pineomatic V5.1 and V6 machines	
BME0000635:00	CATCH M10X1 - PIN Ø6MM	catch m10x1 - pin ø6mm Valid for all Pineomatic V5 machines	
BME0000757:00	QUARTER-TURN LATCH	Quarter-turn Latch Valid for all Pineomatic V5 and V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0000776:00	WINDOW	Window Valid for all Pineomatic V5.1 machines	
BME0004729:00	TOP COVER	Top Cover Valid for all Pineomatic V5 machines	
BME0005142:00	SHAFT	Shaft Valid for all Pineomatic V5.1 and V6 machines	
BME0005760:00	PULLEY HTD 5M-25MM 44 TEETH	Pulley Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0017865:00	HOOK	Hook Valid for all Pineomatic V5 and V5.1 machines	
BME0017921:00	BLOCK	Block Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0020316:00	CURVER BAK	Curver Bak Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0021012:00	FAN	Fan Valid for all Pineomatic V5 and V5.1 machines	


SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0032444:00	DOOR SENSOR	Door sensor Valid for all Pineomatic V5.1 machines	
BME0032580:00	PLATE MM	Plate mm Valid for all Pineomatic V5 and V5.1 machines	
BME0033122:00	ROCKER SWITCH	Rocker switch Valid for all Pineomatic V5 and V5.1 machines	
BME0033123:00	AC SOCKET WITH FUSE HOLDER	C14 Socket With Fuse Holder Valid for all Pineomatic V5 and V5.1 machines	
BME0033171:00	COMPRESSION SPRING	Compression spring Valid for all Pineomatic V5.1 and V6 machines	
BME0036592:00	WHEEL WITH BRACKET	Wheel Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0037409:00	PLUNGER CLAMPS FOR PUSH-PULL CLAMPING	Plunger clamps for push-pull clamping Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0039176:00	SENSOR KNOB	Sensor knob Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0039288:00	MOTOR CONTROLLER	Motor controller Valid for all Pineomatic V5.1 machines	
BME0039320:00	ELECTRIC MOTOR	Electric motor Valid for all Pineomatic V5 and V5.1 machines	
BME0039355:00	DISPLAY	Display Valid for all Pineomatic V5 and V5.1 machines	
BME0039737:00	CONJUNTO CUCHILLA VERTICAL S7	conjunto cuchilla vertical s7 Valid for all Pineomatic V4 machines	
BME0039745:00	CONJUNTO PLACA CUCHILLAS INFERIORES V4 S7	conjunto placa cuchillas inferiores v4 s7 Valid for all Pineomatic V4 machines	
BME0039747:00	KNIFE SLICES	knife slices Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0039755:00	PRENSA SUPERIOR S7	prensa superior s7 Valid for all Pineomatic V4 machines	
BME0040920:00	KEY TRIANGULAR 8MM	Key Triangular 8mm Valid for all Pineomatic V5, V5.1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0040922:00	CABLE	Cable Valid for all Pineomatic V5 and V5.1 machines	
BME0042417:00	THREADED INSERT M4X8	Threaded Insert M4x8 Valid for all Pineomatic V4 and V6 machines	
BME0042418:00	THREADED INSERT M8X12	Threaded Insert M8x15 Valid for all Pineomatic V4 and V6 machines	
BME0044542:00	RIGID COUPLING Ø8MM	Rigid coupling Ø8mm Valid for all Pineomatic V5.1 and V6 machines	
BME0045428:00	TOP KNIFE	top knife Valid for all Pineomatic V5, V5.1 and V6 machines Size 6, 7	
BME0047837:00	THROW IN SENSOR	Throw in sensor Valid for all Pineomatic V5.1 machines	
BME0053496:00	PLATE	Plate Valid for all Pineomatic V5.1 machines	
BME0053709:00	PLATE	Plate Valid for all Pineomatic V5, V5.1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0053927:00	BRACKET MOTOR	Bracket motor Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0054016:00	INLET, FRONT	Inlet, front Valid for all Pineomatic V5.1 machines	
BME0054040:00	MOUNTING ASSEMBLY - VERTICAL GUIDE	Mounting Assembly - Vertical guide Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0054064:00	GUIDE SHAFT VERTICAL	Guide shaft vertical Valid for all Pineomatic V5.1 and V6 machines	
BME0054078:00	COVER RIGHT MM	Cover Right mm Valid for all Pineomatic V5 and V5.1 machines	
BME0054080:00	COVER LEFT MM	Cover Left mm Valid for all Pineomatic V5 and V5.1 machines	
BME0054086:00	SHAFT	Shaft Valid for all Pineomatic V5.1 and V6 machines	
BME0054096:00	WELDING ASSEMBLY INLET	Welding Assembly Valid for all Pineomatic V5 and V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0054112:00	COVER DOOR	Cover door Valid for all Pineomatic V5 and V5.1 machines	
BME0054115:00	MOUNTING ASSEMBLY - DOOR	Mounting assembly - Door Valid for all Pineomatic V5 and V5.1 machines	
BME0054118:00	PLATE	Plate Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0054120:00	GUIDE SHAFT HORIZONTAL	Guide shaft horizontal Valid for all Pineomatic V5.1 and V6 machines	
BME0054126:00	WELDING ASSEMBLY - BEAM FRONT RIGHT	Welding Assembly - Beam front right Valid for all Pineomatic V5 and V5.1 machines	
BME0054127:00	WELDING ASSEMBLY - BEAM FRONT LEFT	Welding Assembly - Beam front left Valid for all Pineomatic V5 and V5.1 machines	
BME0054287:00	PLATE - SIDE PANEL	Plate - side panel Valid for all Pineomatic V5 and V5.1 machines	


SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0054496:00	BLOCK	Block Valid for all Pineomatic V5.1 machines	
BME0054603:00	BLOCK	Block Valid for all Pineomatic V5.1 machines	
BME0054685:00	PLATE	Plate Valid for all Pineomatic V5 and V5.1 machines	
BME0054987:00	SHAFT	Shaft Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0055211:00	PLATE	Plate Valid for all Pineomatic V5.1 machines	
BME0055350:00	BUSH	Bush Valid for all Pineomatic V5.1 machines	
BME0055420:00	SHAFT	Shaft Valid for all Pineomatic V5.1 machines	
BME0056470:00	PCB PINO INCL. SOFTWARE 5.1NSF	PCB Pino Incl. Software 5.1NSF Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0056475:00	GENERAL ARRANGEMENT ELECTRIC BOX	General Arrangement Electric Box Valid for all Pineomatic V5.1 machines	
BME0056485:00	CONNECTOR INSIDE	connector inside Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0056492:00	CONNECTOR	Connector Valid for all Pineomatic V5.1 machines	
BME0056500:00	BUSH	Bush Valid for all Pineomatic V5.1 machines	
BME0056587:00	DEEP GROOVE BALL BEARING 6200-2RSH	Deep groove ball bearing 6200-2RSH Valid for all Pineomatic V5.1 machines	
BME0056591:00	ANGULAR CONTACT BEARING 3201 A-2RS1	Angular contact bearing 3201 A-2RS1 Valid for all Pineomatic V5.1 machines	
BME0057202:00	ENDBLOCK HOR. GUIDE MOTORSIDE	Endblock hor. guide motorside Valid for all Pineomatic V5.1 machines	
BME0057204:00	SPINDLE HOR. GUIDE	Spindle hor. guide Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0057214:00	MOTOR SHAFT	Motor shaft Valid for all Pineomatic V5.1 machines	
BME0057217:00	BUSH	Bush Valid for all Pineomatic V5.1 machines	
BME0057219:00	ENDBLOCK VER. GUIDE MOTORSIDE	Endblock ver. guide motorside Valid for all Pineomatic V5.1 machines	
BME0057321:00	RING	Ring Valid for all Pineomatic V5.1 machines	
BME0057340:00	WELDING ASSEMBLY - TOP PLATE	Welding Assembly - Top plate Valid for all Pineomatic V5.1 machines	
BME0057345:00	PLATE FILLING 195 MM.	Plate filling 195 mm. Valid for all Pineomatic V5.1 machines	
BME0057347:00	STRIP, LEFT UPPER STRUCTURE	Strip, left upper structure Valid for all Pineomatic V5.1 machines	
BME0057351:00	STRIP RIGHT, UPPER STRUCTURE 2MM	Strip right, upper structure 2mm Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0057361:00	PLATE, FILLING	Plate, filling Valid for all Pineomatic V5.1 machines	
BME0057375:00	PLATE, FILLING BACK	Plate, filling back Valid for all Pineomatic V5.1 machines	
BME0057376:00	STRIP SUPPORT UPPER STRUCTURE	Strip support upper structure Valid for all Pineomatic V5.1 machines	
BME0057381:00	ENDBLOCK VER. GUIDE	Endblock ver. guide Valid for all Pineomatic V5.1 machines	
BME0057445:00	HMI TOUCHSCREEN INCL. SOFTWARE 5.1 NSF	HMI Touchscreen Incl. Software 5.1 NSF Valid for all Pineomatic V5 and V5.1 machines	
BME0057446:00	FRAME DISPLAY FRONT	Frame display front Valid for all Pineomatic V5 and V5.1 machines	
BME0057447:00	MOUNTING ASSEMBLY DISPLAY V5	mounting assembly display v5 Valid for all Pineomatic V5 machines	
BME0057470:00	PULLEY - HTD 5M 30 MM. 48 TEETH	Pulley - HTD 5M 30 mm. 48 teeth Valid for all Pineomatic V5 and V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0057651:00	SPINDLE VER. GUIDE	Spindle ver. guide Valid for all Pineomatic V5.1 machines	
BME0057678:00	OPTIBELT TANDRIEM 5M-425-25	Belt HTD 5M 25 mm. T85 (17352000) Mädlar Valid for all Pineomatic V5 and V5.1 machines	
BME0057757:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0057950:00	COVER, ELECTRIC BOX	Cover, electric box Valid for all Pineomatic V5.1 machines	
BME0057975:00	ELECTRIC BOX ASSEMBLY	Electric box assembly Valid for all Pineomatic V5.1 machines	
BME0057983:00	BACKPLATE, TOP STRUCTURE	Backplate, top structure Valid for all Pineomatic V5.1 machines	
BME0057984:00	HORIZONTAL BEAM DOORFRAME BOTTOM	Horizontal beam doorframe bottom Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0058229:00	WELDING ASSEMBLY	Welding Assembly Valid for all Pineomatic V5.1 machines	
BME0058236:00	WELDING ASSEMBLY	Welding Assembly Valid for all Pineomatic V5.1 machines	
BME0058242:00	WELDING ASSEMBLY, FRONT PLATE	Welding Assembly, front plate Valid for all Pineomatic V5.1 machines	
BME0058285:00	SUPPORT PLATE IDENTIFICATION	Support plate identification Valid for all Pineomatic V5.1 machines	
BME0058288:00	COVER REAR	Cover Rear 3mm Valid for all Pineomatic V5 and V5.1 machines	
BME0058312:00	FILLING PLATE	filling plate Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0058314:00	BLOCK, RIGHT (SIZE 7	block, right (size 7 Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0058368:00	FILLING PLATE	filling plate Valid for all Pineomatic V5,1 and V6 machines Size 6	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0058494:00	POWER SUPPLY	Power supply Valid for all Pineomatic V5.1 machines	
BME0058599:00	BEAM, HORIZONTAL LEFT	Beam, horizontal left Valid for all Pineomatic V5.1 machines	
BME0058600:00	BEAM, HORIZONTAL RIGHT	Beam, horizontal right Valid for all Pineomatic V5.1 machines	
BME0058618:00	SCHARNIER	Scharnier Valid for all Pineomatic V5.1 machines	
BME0058719:00	SHAFT, TOP KNIFE RIGHT	Shaft, top knife right Valid for all Pineomatic V5.1 machines	
BME0058926:00	TRANSPORT BLOCK (SIZE 7)	transport block (size 7) Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0059001:00	BLOCK, LEFT (SIZE 7)	block, left (size 7) Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0059335:00	TOP SUPPORT BLOCK HORIZONTAL DRIVE	Top support block horizontal drive Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0059337:00	BOTTOM SUPPORT BLOCK HORIZONTAL DRIVE	Bottom support block horizontal drive Valid for all Pineomatic V5.1 machines	
BME0059341:00	ENDBLOCK HOR. GUIDE	Endblock hor. guide Valid for all Pineomatic V5.1 machines	
BME0059446:00	FRUIT LIFT SUPPORT SHAFT	Fruit lift support shaft Valid for all Pineomatic V5.1 machines	
BME0059755:00	SUPPORT FRONT	support front Valid for all Pineomatic V5,1 and V6 machines	
BME0059759:00	SUPPORT REAR	support rear Valid for all Pineomatic V5,1 and V6 machines	
BME0059800:00	TOP PLATE INNER KNIF	top plate inner knif Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0059839:00	TOP BEAM DOOR FRAME	Top beam door frame Valid for all Pineomatic V5.1 machines	
BME0060932:00	DRIP TRAY	Drip tray Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0060933:00	DRIPTRAY	Drip tray Valid for all Pineomatic V5 and V5.1 machines	
BME0060934:00	DRIPTRAY PLATE	Drip tray plate Valid for all Pineomatic V5 and V5.1 machines	
BME0060961:00	BRACING RIB BASE PLATE LEFT	Bracing rib base plate left Valid for all Pineomatic V5.1 machines	
BME0060962:00	BRACING RIB BASE PLATE RIGHT	Bracing rib base plate right Valid for all Pineomatic V5.1 machines	
BME0060976:00	PLATE FRUIT CORE OPE	plate fruit core ope Valid for all Pineomatic V5,1 and V6 machines	
BME0061121:00	IDENTIFICATION PLATE SIZE 6	identification plate size 6 Valid for all Pineomatic machines Size 6	
BME0061195:00	TRANSPORT BLOCK ASSEMBLY (SIZE 8)	transport block assembly (size 8) Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0061268:00	BLOCK, RIGHT (SIZE 6	block, right (size 6) Valid for all Pineomatic V5,1 and V6 machines Size 6	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0061281:00	BLOCK, LEFT (SIZE 6)	block, left (size 6) Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0061304:00	SHAFT, TOP KNIFE LEFT	Shaft, top knife left Valid for all Pineomatic V5.1 machines	
BME0061788:00	IDENTIFICATION PLATE SIZE 7	identification plate size 7 Valid for all Pineomatic machines Size 7	
BME0061804:00	IDENTIFICATION PLATE SIZE 8	identification plate size 8 Valid for all Pineomatic machines Size 8	
BME0061827:00	12V DC CONNECTOR OPTION SCREEN	12V DC connector option screen Valid for all Pineomatic V5.1 machines	
BME0061930:00	PULLEY WHEEL 20 TEETH HTD 5M 25MM.	Pulley wheel 20 teeth HTD 5M 25mm. Valid for all Pineomatic V5 and V5.1 machines	
BME0062513:00	TOP PLATE INNER KNIFE SIZE 7 10MM	Top plate inner knife size 7 10mm Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0062533:00	TOP PLATE INNER KNIFE SIZE 8 10MM	Top plate inner knife size 8 10mm Valid for all Pineomatic V5,1 and V6 machines Size 8	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0062594:00	CLEANING BUTTON	Cleaning Button Valid for all Pineomatic V5.1 machines	
BME0062730:00	PIN	Pin Valid for all Pineomatic V5.1 machines	
BME0062749:00	PIN	Pin Valid for all Pineomatic V5.1 machines	
BME0062937:00	WELDING ASSEMBLY KNIFE SIZE 6	welding assembly knife size 6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0062949:00	WELDING ASSEMBLY KNIFE SIZE 7	welding assembly knife size 7 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0062957:00	WELDING ASSEMBLY KNIFE SIZE 8	welding assembly knife size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0063085:00	PLATE, SUPPORT COVER LEFT	Plate, support cover left Valid for all Pineomatic V5.1 machines	
BME0063087:00	PLATE, SUPPORT COVER RIGHT	Plate, support cover right Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0063089:00	MOUNTING ASSEMBLY - BOTTOM FRAME	Mounting Assembly - Bottom frame Valid for all Pineomatic V5 and V5.1 machines	
BME0063094:00	WELDING ASSEMBLY - BEAM BACK LEFT	Welding Assembly - Beam back left Valid for all Pineomatic V5.1 machines	
BME0063101:00	WELDING ASSEMBLY - BEAM BACK RIGHT	Welding Assembly - Beam back right Valid for all Pineomatic V5.1 machines	
BME0063250:00	CLAMPING BOLT GN708.1-M6-35-A-ST	Clamping bolt GN708.1-M6-35-A-ST Valid for all Pineomatic V5 and V5.1 machines	
BME0063350:00	BEAM, LIFT	Beam, lift Valid for all Pineomatic V5.1 machines	
BME0063351:00	LIFT ASSEMBLY	Lift assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0063353:00	MOUNTING ASSEMBLY - HORIZONTAL GUIDE NSF	Mounting Assembly - Horizontal Guide NSF Valid for all Pineomatic V5 and V5.1 machines	
BME0063400:00	DISPLAY SUPPORT	Display support Valid for all Pineomatic V5 and V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0063413:00	FABORY 69025.080.030 TYPE 8 OCH 30	Fabory 69025.080.030 type 8 OCH 30 Valid for all Pineomatic V5.1 machines	
BME0063452:00	DISPLAY SUPPORT	Display support Valid for all Pineomatic V5.1 machines	
BME0063482:00	WELDING ASSEMBLY CORE KNIFE SIZE 7	Welding Assembly core knife size 7 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0063526:00	WELDING ASSEMBLY - INNER KNIFE SIZE 6	welding assembly - inner knife size 6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0063578:00	WELDING ASSEMBLY	Welding Assembly Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0063674:00	VERTICAL KNIFE ASSEMBLY (SIZE 6) NSF	vertical knife assembly (size 6) nsf Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0063677:00	PLATE NSF	Plate NSF Valid for all Pineomatic V5,1 and V6 machines	
BME0063679:00	GUIDE RING (SIZE 6) NSF	Guide Ring (Size 6) NSF Valid for all Pineomatic V5,1 and V6 machines Size 6	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0063689:00	GUIDE RING KNIFE (SIZE 7) NSF	Guide Ring Knife (Size 7) NSF Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0063704:00	BOTTOM KNIFE	Bottom Knife Valid for all Pineomatic V5.1 and V6 machines	
BME0063750:00	PLATE	Plate Valid for all Pineomatic V5.1 machines	
BME0063764:00	UPPER STAMP (SIZE 6) NSF	upper stamp (size 6) nsf Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0063769:00	UPPER STAMP	Upper stamp Valid for all Pineomatic V5,1 and V6 machines	
BME0063777:00	SHAFT	shaft Valid for all Pineomatic V5 and V5.1 machines	
BME0063779:00	SHAFT (SIZE 6)	Shaft (Size 6) Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0063781:00	RING	Ring Valid for all Pineomatic V5,1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0063786:00	RING STAMP (SIZE 6) NSF	Ring stamp (Size 6) NSF Valid for all Pineomatic V5,1 and V6 machines	
BME0063787:00	SHAFT UPPER STAMP (SIZE 7 NSF)	Shaft upper stamp (Size 7 NSF) Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0063799:00	PIN UPPER STAMP NSF	pin upper stamp nsf Valid for all Pineomatic V5 and V5.1 machines	
BME0063821:00	BUSH UPPER STAMP NSF	Bush Upper stamp NSF Valid for all Pineomatic V5.1 machines	
BME0063887:00	TOP KNIFE ASSEMBLY (SIZE 6) NSF	top knife assembly (size 6) nsf Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0063944:00	HOUSING HMI	Housing HMI Valid for all Pineomatic V5 and V5.1 machines	
BME0064040:00	BLOCK	Block Valid for all Pineomatic V5,1 and V6 machines	
BME0064220:00	PLATE 1,5MM	Plate 1,5mm Valid for all Pineomatic V5,1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0064228:00	BLOCK TOP KNIFE NFS	Block top knife NFS Valid for all Pineomatic V5,1 and V6 machines	
BME0064235:00	PLATE TOP KNIFE NSF ASSEMBLY	plate top knife nsf assembly Valid for all Pineomatic V5.1 machines	
BME0064283:00	PLATE TRANSPORT BLOCK	Plate transport block Valid for all Pineomatic V5 and V5.1 machines	
BME0064334:00	PLATE, VERTICAL KNIFE SUPPORT	Plate, vertical knife support Valid for all Pineomatic V5.1 machines	
BME0064336:00	PLATE	Plate Valid for all Pineomatic V5.1 machines	
BME0064338:00	PLATE	Plate Valid for all Pineomatic V5.1 machines	
BME0064575:00	BASEPLATE SUPPORT	Baseplate support Valid for all Pineomatic V5.1 machines	
BME0064620:00	CONTACTOR	Contacteur Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0064629:00	SPRING BASEPLATE	Spring baseplate Valid for all Pineomatic V5,1 and V6 machines	
BME0064649:00	MAE-KP-BR-PL	MAE-KP-BR-PL Valid for all Pineomatic V5 and V5.1 machines	
BME0064854:00	LED STRIP PROFILE	led strip profile Valid for all Pineomatic V6 machines Size 7	
BME0065040:00	SHAFT (SIZE 7)	Shaft (Size 7) Valid for all Pineomatic V5,1 and V6 machines Size 7	
BME0065456:00	BUSH	Bush Valid for all Pineomatic V5,1 and V6 machines	
BME0066205:00	SHAFT UPPER STAMP (SIZE 6 NSF)	Shaft upper stamp (Size 6 NSF) Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0066207:00	TOP KNIFE ASSEMBLY (SIZE 7) NSF	top knife assembly (size 7) nsf Valid for all Pineomatic V5.1 and V6 machines Size 7	
BME0066220:00	VERTICAL KNIFE ASSY (SIZE 8) NSF	vertical knife assy (size 8) nsf Valid for all Pineomatic V5.1 machines Size 8	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0066229:00	GUIDE RING KNIFE (SIZE 8) NSF	Guide Ring Knife (Size 8) NSF Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0066240:00	UPPER STAMP (SIZE 8) NSF	upper stamp (size 8) nsf Valid for all Pineomatic V5.1 machines Size 8	
BME0066241:00	SHAFT (SIZE 8)	Shaft (Size 8) Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0066245:00	SHAFT UPPER STAMP (SIZE 8 NSF)	Shaft upper stamp (Size 8 NSF) Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0067051:00	VERTICAL KNIFE ASSEMBLY (SIZE 7) STICKS V6	Vertical Knife Assembly (Size 7) Sticks V6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0067305:00	BASE PLATE (SIZE 7) STICKS & CHUNKS	Base Plate (Size 7) Sticks & Chunks Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0067324:00	PRESS	Press Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0067325:00	PLATE	Plate Valid for all Pineomatic V5, V5.1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0067891:00	PLATE	Plate Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0068435:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068437:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068438:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068439:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068441:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068442:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	
BME0068443:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5 and V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0068478:00	MOUNTING ASSEMBLY BRAKE	Mounting assembly brake Valid for all Pineomatic machines	
BME0068547:00	LED STRIP	led strip Valid for all Pineomatic V5.1 and V6 machines	
BME0068849:00	END CAP LED STRIP PROFILE	end cap led strip profile Valid for all Pineomatic V5.1 and V6 machines	
BME0068851:00	LED STRIP PROFILE	LED strip profile Valid for all Pineomatic V5.1 machines	
BME0071173:00	MOUNTING ASSEMBLY DOOR FRAME	Mounting Assembly Door frame Valid for all Pineomatic V5.1 machines	
BME0071287:00	BASEPLATE ASSEMBLY SIZE 7 V6	Baseplate Assembly Size 7 V6 Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0072063:00	MOUNTING ASSEMBLY	Mounting Assembly Valid for all Pineomatic V5.1 machines	
BME0072097:00	TOP COVER	Top Cover Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0072541:00	INLET, BACK	Inlet, back Valid for all Pineomatic V5.1 machines	
BME0072612:00	WELDING ASSEMBLY	Welding Assembly Valid for all Pineomatic V5.1 machines	
BME0073676:00	PLATE 3MM	plate 3mm Valid for all Pineomatic V5,1 and V6 machines	
BME0074175:00	SHAFT	shaft Valid for all Pineomatic V5,1 and V6 machines	
BME0074554:00	TRANSPORT BLOCK ASSY	transport block assy Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0074557:00	TRANSPORT BLOCK (SIZ	transport block (siz Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0075085:00	TRANSPRT BLOCK ASSY	transprt block assy Valid for all Pineomatic V5,1 and V6 machines Size 6	
BME0075089:00	TRANSPORT BLOCK (SIZ	transport block (siz Valid for all Pineomatic V5,1 and V6 machines Size 6	


SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0075282:00	TOP KNIFE PLATE NSF	top knife plate nsf Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0075284:00	BLOCK, LEFT (SIZE 8)	block, left (size 8) Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0075286:00	BLOCK, RIGHT (SIZE 8)	block, right (size 8) Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0075293:00	ASSEMBLY TOPKNIFE SI	assembly topknife si Valid for all Pineomatic V5,1 and V6 machines Size 8	
BME0077508:00	PART-2024_05_16_11_07_58_0152-DESC	PART-2024_05_16_11_07_58_0152-DESC Valid for all Pineomatic V5.1 machines	
BME0077510:00	BEARING BLOCK VER. GUIDE	Bearing block ver. guide Valid for all Pineomatic V5.1 machines	
BME0077514:00	BEARING BLOCK VER. GUIDE SPINDLE NUT	Bearing block ver. guide spindlenut Valid for all Pineomatic V5.1 machines	
BME0077520:00	BEARING BLOCK HOR. GUIDE	Bearing block hor. guide Valid for all Pineomatic V5.1 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0077527:00	BEARING BLOCK HOR. GUIDE SPINDLENUT	Bearing block hor. guide spindlenut Valid for all Pineomatic V5.1 machines	
BME0077915:00	CAGE FRUIT INTAKE WITH BUSH (7X)	Cage Fruit Intake with bush (7x) Valid for all Pineomatic V5.1 machines	
BME0078292:00	STICKS KNIFE ADAPTER LEFT SIZE 6	Sticks knife adapter LEFT size 6 Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0078295:00	BUSHING STICKS SIZE 6	Bushing sticks Size 6 Valid for all Pineomatic V5, V5.1 and V6 machines	
BME0078302:00	ASSY BUSHING SIZE 6 STICKS V6	Assy bushing Size 6 Sticks V6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0078305:00	ASSEMBLY STICKS ADAPTER SIZE 6	assembly sticks adapter size 6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0078322:00	STICKS KNIFE ADAPTER RIGHT SIZE 6	Sticks knife adapter RIGHT size 6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0079472:00	MOUNTING ASSEMBLY LED STRIP	Mounting Assembly LED strip Valid for all Pineomatic V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0082372:00	WELDING ASSEMBLY - BEAM FRONT RIGHT	Welding Assembly - Beam front right Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0082373:00	WELDING ASSEMBLY - BEAM FRONT LEFT	Welding Assembly - Beam front left Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0082374:00	WELDING ASSEMBLY - BEAM BACK LEFT	Welding assembly - Beam back left Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0082375:00	WELDING ASSEMBLY - BEAM BACK LEFT	Welding Assembly - Beam back left Valid for all Pineomatic V5, V5.1 and V6 machines Size 6	
BME0082455:00	TOP COVER V6	Top Cover V6 Valid for all Pineomatic V6 machines	
BME0082676:00	INLET COVER V6	Inlet Cover V6 Valid for all Pineomatic V6 machines	
BME0082677:00	COVER DOOR V6	Cover Door V6 Valid for all Pineomatic V6 machines	
BME0082684:00	QUARTER-TURN CLASSIC 30 MM	Quarter-Turn Classic 30 mm Valid for all Pineomatic machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0082685:00	HOOK DOOR LOCK 4MM	Hook Door Lock 4mm Valid for all Pineomatic machines	
BME0082686:00	PIN DOOR SENSOR V6	Pin door sensor V6 Valid for all Pineomatic machines	
BME0082735:00	PLATE LEFT SIDE	Plate left side Valid for all Pineomatic V6 machines	
BME0082736:00	PLATE RIGHT SIDE	Plate right side Valid for all Pineomatic V6 machines	
BME0082737:00	PLATE BACK	Plate back Valid for all Pineomatic V6 machines	
BME0082738:00	STRIP WOOD	Strip wood Valid for all Pineomatic V6 machines	
BME0082739:00	STRIP WOOD	Lower Door Window Valid for all Pineomatic V6 machines	
BME0082750:00	STRIP WOOD	Lower Door Window Valid for all Pineomatic V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0082751:00	STRIP WOOD	Lower Door Window Valido para todas las máquinas Pineomatic V6	
BME0082807:00	WELDING ASSEMBLY FRONT PLATE	Welding Assembly front plate Valid for all Pineomatic V6 machines	
BME0082827:00	STICKS KNIFE ADAPTER LEFT SIZE 7	Sticks knife adapter LEFT size 7 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0082831:00	BUSHING STICKS SIZE 7	Bushing sticks Size 7 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0082837:00	STICKS KNIFE ADAPTER RIGHT SIZE 7	Sticks knife adapter RIGHT size 7 Valid for all Pineomatic V5, V5.1 and V6 machines Size 7	
BME0082852:00	ASSY BUSHING SIZE 7 STICKS V6	Assy bushing size 7 sticks V6 Valid for all Pineomatic V6 machines Size 7	
BME0082964:00	UPPER DOOR WINDOW	Upper Door Window Valid for all Pineomatic V6 machines	
BME0083013:00	DOOR HINGE V6	Door hinge V6 Valid for all Pineomatic V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0083342:00	WELDING ASSEMBLY DISPLAY SUPPORT	Welding Assembly Display Support Valid for all Pineomatic V6 machines	
BME0084340:00	ASSEMBLY STICKS ADAPTER SIZE 7	assembly sticks adapter size 7 Valid for all Pineomatic V5 and V5.1 machines Size 7	
BME0084345:00	BUSHING STICKS SIZE 8	Bushing sticks Size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0084350:00	STICKS KNIFE ADAPTER LEFT SIZE 8	Sticks knife adapter Left size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0084358:00	STICKS KNIFE ADAPTER RIGHT SIZE 8	Sticks knife adapter right size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0084362:00	ASSY BUSHING SIZE 8 STICKS V - 6	Assy bushing size 8 sticks V - 6 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0084394:00	ASSEMBLY STICKS ADAPTER SIZE 8	assembly sticks adapter size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0084414:00	PIN LOCK BASEPLATE	Pin lock baseplate Valid for all Pineomatic V5, V5.1 and V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0084738:00	PLATE	Plate Valid for all Pineomatic V6 machines	
BME0084739:00	BOLT	Bolt Valid for all Pineomatic V6 machines	
BME0085148:00	CONTACTOR V-6	Contacteur V-6 Valid for all Pineomatic V6 machines	
BME0085173:00	WELDING ASSEMBLY	Welding Assembly Valid for all Pineomatic V6 machines	
BME0085192:00	GRUB SCREWS SKN - RVS	Grub screws SKN - RVS Valid for all Pineomatic V6 machines	
BME0085251:00	BASE PLATE (SIZE 6) STICKS & CHUNKS	Base Plate (Size 6) Sticks & Chunks Valid for all Pineomatic V5 and V6 machines Size 6	
BME0085260:00	BASE PLATE (SIZE 8) STICKS & CHUNKS	Base Plate (Size 8) Sticks & Chunks Valid for all Pineomatic V5 and V6 machines Size 8	
BME0085266:00	BASEPLATE ASSEMBLY SIZE 6 V6	Baseplate Assembly Size 6 V6 Valid for all Pineomatic V6 machines Size 6	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0085267:00	MOUNTING ASSEMBLY BASEPLATE SIZE 8	Mounting Assembly Baseplate size 8 Valid for all Pineomatic V5, V5.1 and V6 machines Size 8	
BME0085269:00	PLATE BUSHING	Plate Bushing Valid for all Pineomatic V6 machines	
BME0085435:00	CUP HOLDER	Cup Holder Valid for all Pineomatic V6 machines	
BME0085439:00	MOUNTING ASSEMBLY - DOOR	Mounting Assembly - Door Valid for all Pineomatic V6 machines	
BME0086760:00	ASSEMBLY VERTICAL KNIFE SIZE 6 STICKS V6	Assembly Vertical knife Size 6 Sticks V6 Valid for all Pineomatic V6 machines Size 6	
BME0086763:00	ASSEMBLY VERTICAL KNIFE SIZE 8 STICKS V6	Assembly Vertical knife Size 8 Sticks V6 Valid for all Pineomatic V6 machines Size 8	
BME0089948:00	NEW HOOK	New Hook Valid for all Pineomatic V6 machines	
BME0090082:00	M20 TOOTHED WASHER	M20 toothed washer Valid for all Pineomatic V6 machines	

SPARE PARTS CATALOG 2026

PINEOMATIC

	DESCRIPTION	COMPOSITION	PHOTO
BME0090095:00	NEW DOOR PIN	New door pin Valid for all Pineomatic V6 machines	
BME0090235:00	V6 CALIBRATOR	V6 calibrator Valid for all Pineomatic V6 machines	
BME0091975:00	V6 CALIBRATOR	Crownless kit Valid for all Pineomatic V6 machines	